

FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5





FIG. 6



2024-10-12 10:02:10

FIG. 7





FIG. 8






FIG.11



FIG.12




FIG.13

Please select the medium for input
from those shown below

Smart Media	CF Card	Flexible Disc
PC Card	CD-ROM	Photo [Scanner]

Cancel Prev. Screen

FIG.14

Please set the smart medium
and press Reading Start

Cancel Prev. Screen Reading Start

FIG.15

Please set the CF card
and press

FIG.16

Please set the FD
and press

FIG.17







Please set the PC card
and press

FIG.18

Please set the CD-ROM
and press

FIG. 19

Please select the image to be printed,
and input the number of prints

 1 sheet	 1 sheet	 1 sheet
 1 sheet	 1 sheet	 1 sheet

◀ Number of prints Selected Image All Image ▶ Pages 1/5 ▶

Cancel Prev. Screen Determination

FIG. 20

Please select the reading size

Photograph size	A5 size
-----------------	---------

Cancel Prev. Screen

FIG. 21




FIG. 22




FIG. 23

Please set the number of order

Order sheets

FIG. 24

Please select the receiving method

End time scheduled for printing is :

FIG. 25

Please insert money

Number of order sheets

Unit price yen

Total amount yen

Inserted amount yen

FIG. 26

If It is okay,
please press

Number of order sheets

Unit price yen

Total amount yen

FIG. 27




FIG. 28




FIG. 29




FIG. 30




FIG. 31




FIG. 32




FIG. 33




FIG. 34




FIG. 35

Please input your name

Name :

A	B	C	D	E	F	G	H	I
J	K	L	M	N	O	P	Q	R
S	T	U	V	W	X	Y	Z	

FIG. 36

Please input your phone number

Phone No. :

1	2	3	4	5	6	7	8	9	0	-
---	---	---	---	---	---	---	---	---	---	---

FIG. 37

XXXX store

Order Contents

Receipt No. : 0010
Receipt Time: 2000.3.11.10:30
End Time : 2000.3.11.12:00
Scheduled

Name : ○○○○
Phone No. : 03-9876-5432

Menu : Digital Photo
No. of Flames: 8 flames
Total sheets: 20 sheets
Total Amount: 1200 yen

FIG. 37 a

XXXX store

Order Contents

Receipt Na : 0010
Receipt Time: 2000.3.11.10:30
End Time : 2000.3.11.12:00
Scheduled

Box No. : 3
Password : 1 2 3 4 5

Name : ○○○○
Phone No. : 03-9876-5432

Menu : Digital Photo
No. of Flames: 8 flames
Total sheets: 20 sheets
Total Amount: 1200 yen

FIG. 38




FIG. 38 a




FIG. 39




FIG. 40




FIG. 41




FIG. 42




FIG. 43

















Please select the medium for input
from those shown below

Smart Media	CF Card	Flexible Disc
PC Card	CD-ROM	Touch Button for your selection

Cancel Prev. Screen

FIG. 44

Please confirm the screen
and press **Determination**

				Pages No. 3/4
				
				
				

◀ ▶

Cancel Prev. Screen Determination

FIG. 45

Please insert money	
Number of index	<input type="text" value="2"/> sheets
Unit price	<input type="text" value="120"/> yen
Total amount	<input type="text" value="240"/> yen
<hr/>	
Inserted amount	<input type="text" value="0"/> yen
<div><input type="button" value="Cancel"/> <input type="button" value="Prev. Screen"/></div>	

FIG. 46

By which size will this be printed?	
Size	<input type="text" value="1"/> Visa size
	<input type="text" value="2"/> driver's license size
	<input type="text" value="3"/> Curriculum vitae size
	<input type="text" value="4"/> Passport size
Color	<input type="text" value="Color"/>
	<input type="text" value="Monochrome"/>
<div><input type="button" value="Cancel"/> <input type="button" value="Prev. Screen"/> <input type="button" value="Determination"/></div>	

FIG. 47


Please insert money

Unit price yen

Inserted amount yen

FIG. 48

Please select the image to be printed



Touch photo for your selection

FIG. 49

Please touch a button for selection

Postcard data new production

FD reading/photo printer output

Cancel Prev. Screen

FIG. 50

Please insert money

Total amount 360 yen

Inserted amount 0 yen

Cancel

FIG. 51

Please receive at counter

End time scheduled for printing is 00:00

Confirmation

Cancel Prev. Screen

099141 10701
FD2021 101260

FIG. 52




FIG. 53




FIG. 54




FIG. 55




FIG. 56




FIG. 57




FIG. 58




FIG.59




FIG. 60

Your ordered prints will be stored
in the rocker box located at the
entrance of this shop

Please input password for setting
to your box

Password:

1 2 3 4 5 6 7 8 9 0

FIG. 61

Please confirm your order content

Receipt No. : 0 0 1 0	Menu : Digital photo
Time : 2000.3.11.10:30	Number of Flames : 8 flames
End Time : 2000.3.11.12:00	Total Sheets : 20 sheets
Scheduled Box No. : 3	Total Amount : 1200Yen
Password : 1 2 3 4 5	
Name : ○○○○	
Phone No. : 03-9876-5432	

FIG. 62




FIG. 63




FIG. 64




FIG. 65




FIG. 66




FIG. 67




FIG. 68




FIG. 69




FIG. 70




FIG. 71




FIG. 73




FIG. 72




FIG. 75




FIG. 76





FIG.74



09021404 1120701

FIG. 77




FIG. 78 a




FIG. 78 b




FIG. 78 c




FIG. 79




FIG. 80

